
Salice Wind


Assembly Instructions



Fixing the plates to the cabinet sides



Fixing the cups to the door





Deploying the system to the cups

· This operation is tool free

Installing the system to the plates.

- · Insert the system until back fixing is engaged.
- · This operation is tool free.








Installing the covers



WARNING! Security cable ties.
Remove the cable ties only at the end of the assembly. Use the instructions and the QR Code attached to the systems.








Adjustments

- 1. Adjustment of the spring strength.
- 2. Adjustment of the decelerating effect.
- 3. Extension/adjustment of the opening angle of the door.
- 4. Height adjustment of the door from 2 to +2.
- 5. Sideways adjustment of the door from 2 to+2.
- 6. Depth adjustment of the door from 1 to +3.







Removal of the covers

Disassembly of the system.

- Press the back lever and pull out the system.
- This operation is tool free.





Unfasten the system from the cups.

- · Disconnecting the system from the cups.
- This operation is tool free.

